

01 **A B C**

DO NOT REMOVE RIBBONS
LOOK AT LABELS ON FRAME ELEMENTS

WALL

4

3

2

1

4x

02 **A B C**

LIFT & MOVE TILL STOPPER

PUSH DOWN TO LOCK IN PLACE

TOOL

USE TOOL TO TURN WHEEL CLOCKWISE

GRAB HERE

GRAB HERE

TURN TO LOCK

DO NOT TWIST

4x

4x

2x

2x

03 **D**

USE ASSEMBLY SUPPORT TO ASSEMBLE LEGS

4x

04 **E F**

2x

2x

05 **G H I J**

DO NOT PLUG IN POWER SUPPLY BEFORE FINISHING ASSEMBLY!

2 pin

12 pin

10 pin

12 pin

2 pin

J

I

G

H

J

2x

J

06 **K L M N O**

START WITH PLATFORM L (HEAD)

01

02

03

04

HEAD

BASE

LEG

FOOT

REMOVE ALL RIBBONS BEFORE MOUNTING THE PLATFORMS!

07 **J L**


MOUNT USB MODULES ON BASE PLATFORM

2x


08

Before using your Yaasa Adjustable Bed for first time, please:


- Put mattress on base.
- Plug in your Yaasa Adjustable Bed.
- Activate your bed with the remote control.



QUICK START GUIDE **USER MANUAL**




2 x AAAA BATTERIES




REMOTE CONTROL



ASSEMBLY SUPPORT



TOOL



O 14x MOUNTING SCREW **P** 4x MOUNTING SCREW



N PLATFORM ELEMENT (FOOT)



M PLATFORM ELEMENT (LEG)



L PLATFORM ELEMENT (BASE)




K PLATFORM ELEMENT (HEAD)


YAASA

The Yaasa Adjustable Bed

YAASA



Remote Control



Head Position Up

Head Position Down

Favorite Position 1
Hold for 3 seconds to save position
Default: Anti-snore

Favorite Position 2
Hold for 3 seconds to save position
Default: Zero-Gravity

Foot Position Up

Flat Position

Foot Position Down

Child Lock
Hold for 3 seconds to lock / unlock.

2x AAAA

For further details read the Owner's Manual.

help.yaasa.com


Components Overview

The Yaasa Adjustable Bed

Quick Start Guide



J 2x USB MODULE




I SIDE TO SIDE CABLE



H POWER CABLE




G POWER CONVERTER




E 2x CORNER CONNECTOR COVER (TYPE A)


F 2x CORNER CONNECTOR COVER (TYPE B)



D 4x LEG



B SIDE RAIL (RIGHT)



A SIDE RAIL (LEFT)

YAASA

